

DY3000DT Smart Internet APP

USER MANUAL

DAYANG

Contents

Preface	2
Download and install Smart Internet APP	3
Account information interface	4
User Registration	4
User login.....	6
Forget password.....	6
Binding vehicle.....	7
Vehicle condition interface	8
Connecting Bluetooth.....	8
Disconnect Bluetooth.....	8
Mobile phone unlocking	9
Automatic unlocking.....	9
Electronic Fence	10
Riding information	11

Service interface	13
Vehicle condition self inspection.....	13
Service Station.....	14
Online repair.....	15
Repair record	16
Guide to use.....	16
Fault code.....	17
Finding interface	18
Homepage	18
Change background image	18
Home page.....	19
Vehicle Management.....	19
Personalization setting.....	22
Message notification.....	23
Help	24
Setting	24

Preface

This manual introduces the basic operation method of the Smart internet APP. Please read it carefully.

If you have any questions about the contents, supplement or use of the instruction manual, please consult your local dealer or the marketing department of our company.

The contents and notes of this manual are edited and published according to the latest information. We have no obligation to inform you in advance if there is any change later.

All rights reserved. If you need to quote, please contact our company.

Thank you for choosing our electrical motorcycle, Wish you happy and comfortable life it bring to you in the future.

Download and install Smart Internet APP

Please scan the following QR code with your mobile phone, Download and install Smart Internet APP according to prompt, and enjoy intelligent travel.




Note:

- Your phone needs to have Bluetooth function version 4.0 or above;
- iOS version 10.0 or above;
- Android TM Android version 8.0 or above.


Account information interface

User Registration

1. Open APP, enter the following page.
2. Click **binding device** button.



3. Jump to Login page, click **Register** button.



4. Enter into Register page, select country code, enter phone number, verification code and password, click Register button.

register

+86 ▾ please enter phone number

please enter verification [get verification](#)

please enter password

read and agree to [《EULA》](#)


register

< select country

China	+ 86
Netherlands	+ 31
Greece	+ 30
Thailand	+ 66
France	+ 33

User login


In login page, you enter phone number and keyword to login.



The login form is titled "welcome back". It features a phone number input field with a dropdown menu showing "+86" and a placeholder "please enter phone num". Below it is a password input field with a placeholder "please enter password". There are two buttons: a red "log in" button and a white "register" button. At the bottom, there is a link for "forget password?".

Forget password


1. Click login page forget password button below the Register button.
2. Enter Reset password page, input the phone number, verification code and new password and click OK.




The reset password form is titled "reset password". It features a phone number input field with a dropdown menu showing "+86" and a placeholder "please enter phone num". Below it is a verification code input field with a placeholder "please enter verification" and a "get code" button. Below that is a password input field with a placeholder "please enter password". At the bottom, there is a red "ok" button.

Binding vehicle

1. Click **binding device** to enter binding page. Support scan QR code to add, manually fill in SN.




2. Click **the QR code scanning box** to scan **the bind QR code**, or manually fill in the SN, wait for VIN, Motor number and other information to be displayed automatically, and then click Save. Bind QR code is in 《DYEGO app quick installation instruction》 in Key box.



Vehicle condition interface


Connecting Bluetooth

Open Bluetooth of mobile phone, click Blue tooth in the upper right corner of vehicle condition interface, enter Bluetooth matching interface, and click **binding**.



Disconnect Bluetooth

After connecting Bluetooth, click **Unbinding** button to disconnect Bluetooth.




Mobile phone unlocking

After **connecting Bluetooth**, click unlock button on vehicle condition page the vehicle unlocked.


Automatic unlocking

Turn on the automatic unlocking function, when the mobile phone close to the vehicle, press the ignition switch knob to realize inductive unlocking. To use this function, you need to set the permissions of the mobile phone to ensure that the app can run in the background of the mobile phone. When you open this function, you should be careful not to lose the vehicle.




Electronic Fence

1. Open electronic fence : Click the following icon to enter electronic fence page.



2.Set fence parameters:

Enter the name of the fence, edit the address、 radius and type of the center fence, and click the **save button** to save. Move and click on the map to select the fence center.




3.Add/Delete Fence:

Add fence: Up to 5 fences can be added.

Turn on the fence: Click the fence switch to turn on/off the fence. One fence can be turn on at a time.


Delete fence: Click **delete** and **confirm** in the confirmation dialog box.



Riding information


1. The latest riding data can be viewed on the home page.


2. Click **more** button to enter riding information page.





3. Click riding record upper right corner to enter riding statistics page.







Service interface

Vehicle condition Self inspection


Click **self check** button to start self inspection of the vehicle.





Service Station


1. Search service station: Enter the service station page, click search box, enter address/name.



2. Click the business hall data in the list to display the specific map location of the service station.

3. Telephone: Click on the phone, the phone number will pop up, you can choose to dial.

4. Report for repair: Click **repair** to enter **on-line repair** page and select service station. Fill in the contact information and problem description, and click the top right corner **submit** to submit.



The screenshot shows a mobile application interface for reporting a repair. At the top, there is a navigation bar with a back arrow on the left, the title 'online repair' in the center, and a red 'submit' button on the right. Below the navigation bar, there are several input fields and buttons: a 'Service center' field with the value 'ceshi20210505' and a 'switch >' button; a 'repair equipment' field with a 'select equipment >' button; a 'contact' field with the placeholder 'enter contact'; and a 'problem description' field with the placeholder 'please enter problem'.


Online repair

Click **repair** in service station page or click **online repair** to report repair.

Repair record

1. Click **repair record** to view the record of repairing.


2. Click a record to view the details, click **repair result** to view repair result.



Guide to use


1. Enter the product manual page and click to view the manual.





Fault code

Click to view the meaning of the **fault code**




Finding interface

UNDER CONSTRUCTION

Homepage

Change background image


Enter **homepage**, click top left icon, then click to take a picture or select from the mobile phone album to change the background image.



Home page


1. Click the **homepage** in the top right corner of my interface or click the avatar to enter the **personal home page**.

2. Edit personal data: Click the icon in the top right corner of the personal home page to enter the personal information page. You can change your avatar, change your nickname, gender, birthday and profile. After modification, click the top right corner save button to save.



Vehicle Management


1. Enter vehicle management, you can view binding vehicle.



2. Binding the vehicle

The procedure of **binding vehicle** is the same as that on page 7.


3. Set as Default: When binding multiple vehicles at the same time, click **set to track** display vehicle to set the vehicle as the current vehicle.



3. Unbinding vehicle: Click **Unbinding the vehicle**, then click **confirm unbinding**.



4. View vehicle information: Click the **vehicle picture** to enter the vehicle information page.



5. Firmware information: Clicks **OTA upgrade** to view version information.

6. OTA upgrade:

①Ignition switch is in ON position.

②Open the Bluetooth of mobile phone, and the app completes the Bluetooth connection. See page 9 for Bluetooth connection steps.

③Click the green upgrade arrow after the name of upgradable part.

④The upgrade complete dialog box will pop up.

Attention:


①When upgrading, do not exit the upgrade interface, keep the mobile phone within 2m of the vehicle, and keep the mobile phone screen on, otherwise the upgrade will fail.


②After the upgrade progress is completed, it will take some time to “verify and wait”. When the “upgrade completed” dialog box pops up, you can exit the upgrade interface.

③It is normal for the vehicle to restart after the lithium battery upgrade.

④The version number update indicates that the upgrade is complete.

⑤Please upgrade where the network signal is good.






Personalization setting

1. When the positioning and network symbols appear in the instrument, you can enter the personalization setting, and the symbols are as follows.




2. Enter the personalized setting interface to set alarm sound, instrument color, side stand status etc.. After setting, clicks save.




Message notification

The information of alarm, interaction and system can be viewed.




Help

1. Enter **Help**, you can view the app manual and other contents.




Setting

1. Account security management: You can change mobile phone number, login password.



2.Push setting: Alarm push mode can be set.



3.About APP: You can click to find out whether the app is the latest version. When the app has a new version, click upgrade and the app will be upgraded to the latest version.

